

Printer Compatibility List for TL-PS110U/TL-PS110P/TL-WPS510U

Update:2009-09-08

Note: "OK" means the print server is compatible with the printer;

" \" means the print server is not compatible with the printer;

"—" means the function is not tested.

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
1	HP	Business Ink Jet	OK		OK
2	HP	Color LaserJet 1500L	OK		OK
3	HP	Color LaserJet 1600	OK		OK
4	HP	Color LaserJet 2500	OK	OK	OK
5	HP	Color LaserJet 2550	OK	OK	OK
6	HP	Color LaserJet 2550L/LN	OK		OK
7	HP	Color LaserJet 2600	OK		OK
8	HP	Color LaserJet 2600N	OK		OK
9	HP	Color LaserJet 2605	OK	OK	OK
10	HP	Color LaserJet 2700N	OK		OK
11	HP	Color LaserJet 2840	OK		OK
12	HP	Color LaserJet 3550		OK	
13	HP	Color LaserJet 3700	OK	OK	OK
14	HP	Color LaserJet 4000		OK	
15	HP	Color LaserJet 4100		OK	
16	HP	Color LaserJet 4500		OK	
17	HP	Color LaserJet 4650	OK	OK	OK
18	HP	Color LaserJet 8550		OK	
19	HP	DesignJet 100	OK	OK	OK
20	HP	DesignJet 600		OK	
21	HP	DesignJet 650C		OK	
22	HP	DesignJet 700		OK	
23	HP	DesignJet 750C+		OK	
24	HP	DeskJet 1120C		OK	
25	HP	DeskJet 1125C	OK	OK	OK
26	HP	DeskJet 1180C	OK	OK	OK
27	HP	DeskJet	OK		OK
28	HP	DeskJet 1280	OK	OK	OK
29	HP	DeskJet 3325	OK		OK
30	HP	DeskJet 3420	OK		OK
31	HP	DeskJet 3535	OK		OK
32	HP	DeskJet 3650	OK		OK
33	HP	DeskJet 3743	OK		OK
34	HP	DeskJet 3748	OK		OK
35	HP	DeskJet 3820	OK	OK	OK
36	HP	DeskJet 3920	OK		OK
37	HP	DeskJet 3940	OK		OK
38	HP	DeskJet 400/420		OK	
39	HP	DeskJet 450C	OK	OK	OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
40	HP	DeskJet 500/550C		OK	
41	HP	DeskJet 5440	OK		OK
42	HP	DeskJet 5500		OK	
43	HP	DeskJet 5550	OK	OK	OK
44	HP	DeskJet 5652	OK	OK	OK
45	HP	DeskJet 670C		OK	
46	HP	DeskJet 680C		OK	
47	HP	DeskJet 720C		OK	
48	HP	DeskJet 810C	OK	OK	OK
49	HP	DeskJet 830C	OK	OK	OK
50	HP	DeskJet 845C	OK		OK
51	HP	DeskJet 920C		OK	
52	HP	DeskJet 930C		OK	
53	HP	DeskJet 9300	OK	OK	OK
54	HP	DeskJet 948C	OK	OK	OK
55	HP	DeskJet 9600	OK	OK	OK
56	HP	DeskJet 9650	OK	OK	OK
57	HP	DeskJet 970C XI	OK	OK	OK
58	HP	DeskJet 9800	OK	OK	OK
59	HP	DeskJet D1560	OK		OK
60	HP	DeskJet D2360	OK		OK
61	HP	DeskJet D2460	OK		OK
62	HP	DeskJet D2560	OK		OK
63	HP	DeskJet F370	OK		OK
64	HP	DeskJet F380	OK		OK
65	HP	DeskJet F4185	OK		OK
66	HP	DeskJet F4280	OK		OK
67	HP	LaserJet 1005 MFP	OK		OK
68	HP	LaserJet 1010			OK
69	HP	LaserJet 1022	OK		OK
70	HP	LaserJet 1022N	OK		OK
71	HP	LaserJet 1100		OK	
72	HP	LaserJet M1120MFP	OK		OK
73	HP	LaserJet 1160	OK	OK	OK
74	HP	LaserJet 1200	OK	OK	OK
75	HP	LaserJet 1220	OK	OK	OK
76	HP	LaserJet 1300	OK	OK	OK
77	HP	LaserJet 1320	OK	OK	OK
78	HP	LaserJet 2100		OK	
79	HP	LaserJet 2200		OK	
80	HP	LaserJet 2200D	OK	OK	OK
81	HP	LaserJet 2300	OK	OK	OK
82	HP	LaserJet 2410	OK	OK	OK
83	HP	LaserJet 2420	OK	OK	OK
84	HP	LaserJet 2500	OK	OK	OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
85	HP	LaserJet 2550	OK	OK	OK
86	HP	LaserJet 3015	OK	OK	OK
87	HP	LaserJet 3050	OK		OK
88	HP	LaserJet 3055	OK		OK
89	HP	LaserJet 3200	OK	OK	OK
90	HP	LaserJet 3330	OK	OK	OK
91	HP	LaserJet 3330MFP	OK	OK	OK
92	HP	LaserJet 3380	OK		OK
93	HP	LaserJet 4000		OK	
94	HP	LaserJet 4050		OK	
95	HP	LaserJet 4100 /4100N		OK	
96	HP	LaserJet 4250	OK	OK	OK
97	HP	LaserJet 4300	OK	OK	OK
98	HP	LaserJet 4300	OK	OK	OK
99	HP	LaserJet 4500		OK	
100	HP	LaserJet 4650	OK	OK	OK
101	HP	LaserJet 5000	OK	OK	OK
102	HP	LaserJet 5000LE		OK	
103	HP	LaserJet 5100IE/SE		OK	
104	HP	LaserJet 6P / 6L		OK	
105	HP	LaserJet 8100		OK	
106	HP	LaserJet M1005	OK		OK
107	HP	LaserJet M1005 MFP	OK		OK
108	HP	LaserJet M1120 MFP	OK		OK
109	HP	LaserJet P2015	OK		OK
110	HP	OfficeJet 4255	OK		OK
111	HP	OfficeJet 5510	OK		OK
112	HP	OfficeJet 5510	OK		OK
113	HP	OfficeJet 5610	OK		OK
114	HP	OfficeJet 6210	OK		OK
115	HP	OfficeJet 6310	OK		OK
116	HP	OfficeJet 7210	OK		OK
117	HP	OfficeJet J4580	OK		OK
118	HP	OfficeJet J6480	OK		OK
119	HP	OfficeJet K7100	OK		OK
120	HP	OfficeJet K850	OK	OK	OK
121	HP	OfficeJet Pro K5300	OK		OK
122	HP	OfficeJet Pro K550	OK		OK
123	HP	OfficeJet Pro L7380	OK		OK
124	HP	OfficeJet Pro L7590	OK		OK
125	HP	Photosmart 2610	OK		OK
126	HP	Photosmart 3110	OK		OK
127	HP	photosmart 7150	OK		OK
128	HP	photosmart 7200	OK		OK
129	HP	photosmart 7550	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
130	HP	photosmart 7660	OK		OK
131	HP	photosmart 7830	OK		OK
132	HP	photosmart 7900	OK		OK
133	HP	Photosmart 8200	OK		OK
134	HP	Photosmart C3180	OK		OK
135	HP	Photosmart C4180	OK		OK
136	HP	Photosmart C4280	OK		OK
137	HP	Photosmart C4385	OK		OK
138	HP	Photosmart C4480	OK		OK
139	HP	Photosmart C4580	OK		OK
140	HP	Photosmart C5280	OK		OK
141	HP	Photosmart C5380	OK		OK
142	HP	Photosmart C6180	OK		OK
143	HP	Photosmart C6380	OK		OK
144	HP	Photosmart C7280	OK		OK
145	HP	Photosmart D5160	OK		OK
146	HP	Photosmart D5360	OK		OK
147	HP	Photosmart D5460	OK		OK
148	HP	Photosmart D7160	OK		OK
149	HP	Photosmart D7260	OK		OK
150	HP	PSC 1210	OK		OK
151	HP	PSC 1315	OK		OK
152	HP	PSC 1350	OK		OK
153	HP	PSC 1410	OK		OK
154	HP	PSC 1610	OK		OK
155	HP	PSC 2210	OK		OK
156	HP	PSC 2310	OK		OK
157	EPSON	AcuLaser C1900	OK	OK	OK
158	EPSON	AcuLaser C3800	OK		OK
159	EPSON	AcuLaser C9100	OK		OK
160	EPSON	C750	OK	OK	OK
161	EPSON	CC-500L	OK		OK
162	EPSON	CL-760	OK		OK
163	EPSON	CX2900	OK		OK
164	EPSON	CX 3500	OK		OK
165	EPSON	CX 3700	OK		OK
166	EPSON	CX 3900	OK		OK
167	EPSON	CX 4100	OK		OK
168	EPSON	CX 4900	OK		OK
169	EPSON	CX 5500	OK		OK
170	EPSON	CX 5505	OK		OK
171	EPSON	CX 5900	OK		OK
172	EPSON	CX6900F	OK		OK
173	EPSON	CX 8300	OK		OK
174	EPSON	E-300L	OK		OK
175	EPSON	E-520	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
176	EPSON	E-720	OK		OK
177	EPSON	EC-01	OK		OK
178	EPSON	EPL 5700		OK	
179	EPSON	EPL 5800	OK	OK	OK
180	EPSON	EPL 5900	OK	OK	OK
181	EPSON	EPL 6100	OK	OK	OK
182	EPSON	EPL 6200	OK	OK	OK
183	EPSON	EPL 6200L	OK		OK
184	EPSON	EPL N2120		OK	
185	EPSON	LP2500	OK		OK
186	EPSON	LP-7700	OK		OK
187	EPSON	LP-8700	OK		OK
188	EPSON	LP-8800C	OK		OK
189	EPSON	LP8900	OK		OK
190	EPSON	LP-9500C	OK		OK
191	EPSON	LQ 100		OK	
192	EPSON	LQ 1000C		OK	
193	EPSON	LQ 1170+		OK	
194	EPSON	LQ 1170C		OK	
195	EPSON	LQ 1170C+		OK	
196	EPSON	LQ 2070C		OK	
197	EPSON	LQ 2080C		OK	
198	EPSON	LQ 2090		OK	
199	EPSON	LQ 2090C	OK	OK	OK
200	EPSON	LQ 2170C		OK	
201	EPSON	LQ 2180C		OK	
202	EPSON	LQ 2550		OK	
203	EPSON	LQ 300		OK	
204	EPSON	LQ 300+		OK	
205	EPSON	LQ 300+II	OK	OK	OK
206	EPSON	LQ 3500C		OK	
207	EPSON	LQ 570C		OK	
208	EPSON	LQ 670		OK	
209	EPSON	LQ 680		OK	
210	EPSON	LQ 680C		OK	
211	EPSON	MC-2000	OK		OK
212	EPSON	ME1			
213	EPSON	PictureMate PM250	OK		OK
214	EPSON	PM-860PT	OK		OK
215	EPSON	PM-890C	OK		OK
216	EPSON	PM-920C	OK		OK
217	EPSON	PM-930C	OK		OK
218	EPSON	PM-950C	OK		OK
219	EPSON	PM-970C	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
220	EPSON	PM-980C	OK		OK
221	EPSON	PM-A550	OK		OK
222	EPSON	PM-A620	OK		OK
223	EPSON	PM-A650	OK		OK
224	EPSON	PM-A720	OK		OK
225	EPSON	PM-A820	OK		OK
226	EPSON	PM-A840	OK		OK
227	EPSON	PM-A850	OK		OK
228	EPSON	PM-A890	OK		OK
229	EPSON	PM-A900	OK		OK
230	EPSON	PM-A920	OK		OK
231	EPSON	PM-A940	OK		OK
232	EPSON	PM-A950	OK		OK
233	EPSON	PM-A970	OK		OK
234	EPSON	PM-2200C	OK		OK
235	EPSON	PM-3500C	OK		OK
236	EPSON	PM-3700C	OK		OK
237	EPSON	PM-4000PX	OK		OK
238	EPSON	PM-D800	OK		OK
239	EPSON	PM-D870	OK		OK
240	EPSON	PM-D1000	OK		OK
241	EPSON	PM-FA700	OK		OK
242	EPSON	PM-G800	OK		OK
243	EPSON	PM-G820	OK		OK
244	EPSON	PM-G850	OK		OK
245	EPSON	PM-G860	OK		OK
246	EPSON	PM-G4500	OK		OK
247	EPSON	PM-T960	OK		OK
248	EPSON	PM-T990	OK		OK
249	EPSON	PX-5000	OK		OK
250	EPSON	PX-A640	OK		OK
251	EPSON	PX-A740	OK		OK
252	EPSON	PX-G5300	OK		OK
253	EPSON	PX-G5100	OK		OK
254	EPSON	PX-G930	OK		OK
255	EPSON	PX-G5000	OK		OK
256	EPSON	PX-V780	OK		OK
257	EPSON	RX 510	OK		OK
258	EPSON	RX 530	OK		OK
259	EPSON	RX 590	OK		OK
260	EPSON	RX 630	OK		OK
261	EPSON	RX 690	OK		OK
262	EPSON	Stylus C20	OK		OK
263	EPSON	Stylus C40	OK		OK
264	EPSON	Stylus C41UX/SX	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
265	EPSON	Stylus C43UX	OK		OK
266	EPSON	Stylus C45	OK		OK
267	EPSON	Stylus C59	OK		OK
268	EPSON	Stylus C60	OK	OK	OK
269	EPSON	Stylus C63	OK	OK	OK
270	EPSON	Stylus C67	OK	OK	OK
271	EPSON	Stylus C79	OK		OK
272	EPSON	Stylus C83		OK	
273	EPSON	Stylus C90	OK		OK
274	EPSON	Stylus Color 1160	OK		OK
275	EPSON	Stylus Color 1500	OK		OK
276	EPSON	Stylus Color 1520	OK		OK
277	EPSON	Stylus Color 400		OK	
278	EPSON	Stylus Color 460			
279	EPSON	Stylus Color 600		OK	
280	EPSON	Stylus Color 640			
281	EPSON	Stylus Color 660			
282	EPSON	Stylus Color 670	OK	OK	OK
283	EPSON	Stylus Color 800	OK	OK	OK
284	EPSON	Stylus Color 810	OK	OK	OK
285	EPSON	Stylus Color 850	OK	OK	OK
286	EPSON	Stylus Color 900	OK		OK
287	EPSON	Stylus CX-1500	OK		OK
288	EPSON	Stylus CX-2900	OK		OK
289	EPSON	Stylus CX-3500	OK		OK
290	EPSON	Stylus CX-3700	OK		OK
291	EPSON	Stylus CX-3900	OK		OK
292	EPSON	Stylus CX-4100	OK		OK
293	EPSON	Stylus CX-4700	OK		OK
294	EPSON	Stylus CX-4900	OK		OK
295	EPSON	Stylus CX-5300	OK		OK
296	EPSON	Stylus CX-5500	OK		OK
297	EPSON	Stylus CX-5505	OK		OK
298	EPSON	Stylus CX-5900	OK		OK
299	EPSON	Stylus CX-6900F	OK		OK
300	EPSON	Stylus CX-7300	OK		OK
301	EPSON	Stylus CX-7800	OK		OK
302	EPSON	Stylus CX-8300	OK		OK
303	EPSON	Stylus CX-9300F	OK		OK
304	EPSON	Stylus Office T30	OK		OK
305	EPSON	Stylus Office TX300F	OK		OK
306	EPSON	Stylus Office TX600FW	OK		OK
307	EPSON	Stylus Office TX700W	OK		OK
308	EPSON	Stylus Photo 915	OK		OK
309	EPSON	Stylus Photo 1270	OK	OK	OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
310	EPSON	Stylus Photo 1290	OK		OK
311	EPSON	Stylus Photo 1390	OK		OK
312	EPSON	Stylus Photo 2100	OK		OK
313	EPSON	Stylus Photo 710	OK		OK
314	EPSON	Stylus Photo 720	OK		OK
315	EPSON	Stylus Photo 790	OK		OK
316	EPSON	Stylus Photo 810	OK	OK	OK
317	EPSON	Stylus Photo 830U	OK		OK
318	EPSON	Stylus Photo 900	OK	OK	OK
319	EPSON	Stylus Photo 915	OK		OK
320	EPSON	Stylus Photo EX2	OK	OK	OK
321	EPSON	Stylus Photo EX3	OK	OK	OK
322	EPSON	Stylus Photo R1800	OK	OK	OK
323	EPSON	Stylus Photo R210	OK		OK
324	EPSON	Stylus Photo R230	OK		OK
325	EPSON	Stylus Photo R250	OK		OK
326	EPSON	Stylus Photo R270	OK		OK
327	EPSON	Stylus Photo R310	OK		OK
328	EPSON	Stylus Photo R350	OK		OK
329	EPSON	Stylus Photo R2400	OK		OK
330	EPSON	Stylus Photo R800	OK		OK
331	EPSON	Stylus Photo RX430	OK		OK
332	EPSON	Stylus Photo RX 510	OK		OK
333	EPSON	Stylus Photo RX 530	OK		OK
334	EPSON	Stylus Photo RX 590	OK		OK
335	EPSON	Stylus Photo RX 630	OK		OK
336	EPSON	Stylus Photo RX 650	OK		OK
337	EPSON	Stylus Photo RX 690	OK		OK
338	EPSON	Stylus Photo TX700W	OK		OK
339	EPSON	Stylus Photo TX600FW	OK		OK
340	EPSON	Stylus Photo TX800FW	OK		OK
341	EPSON	Stylus Pro 7600	OK	OK	OK
342	EPSON	T20	OK		OK
343	EPSON	T40W	OK		OK
344	EPSON	TM883 (III)		OK	
345	EPSON	TM T88III		OK	
346	EPSON	TX100	OK		OK
347	EPSON	TX200	OK		OK
348	Canon	BJC-330		OK	
349	Canon	BJC-4200		OK	
350	Canon	BJC-4300		OK	
351	Canon	BJC-4550		OK	
352	Canon	BJC-4600		OK	
353	Canon	BJF9000	OK		OK
354	Canon	D380	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
355	Canon	I-255	OK		OK
356	Canon	I-355	OK		OK
357	Canon	I-450	OK		OK
358	Canon	I-455	OK		OK
359	Canon	I-470D	OK		OK
360	Canon	I-475D	OK		OK
361	Canon	I-550	OK		OK
362	Canon	I-560	OK		OK
363	Canon	I-850	OK		OK
364	Canon	I-865	OK		OK
365	Canon	I-950	OK		OK
366	Canon	I-6100	OK	OK	OK
367	Canon	I-6500	OK	OK	OK
368	Canon	I-9100	OK		OK
369	Canon	I-9950	OK		OK
370	Canon	IX4000	OK		OK
371	Canon	IX5000	OK		OK
372	Canon	Imageclass D380	OK		OK
373	Canon	MP-110	OK		OK
374	Canon	MP-130	OK		OK
375	Canon	MP 145	OK		OK
376	Canon	MP-150	OK		OK
377	Canon	MP-160	OK		OK
378	Canon	MP 180	OK		OK
379	Canon	MP 730	OK		OK
380	Canon	MP 770	OK		OK
381	Canon	MP 780	OK		OK
382	Canon	MX318	OK		OK
383	Canon	MX700	OK		OK
384	Canon	PIXUS iP2500	OK		OK
385	Canon	PIXUS 990i	OK		OK
386	Canon	PIXMA iP1000	OK		OK
387	Canon	PIXMA iP1700	OK		OK
388	Canon	PIXMA iP1800	OK		OK
389	Canon	PIXMA iP1880	OK		OK
390	Canon	PIXMA iP2000	OK		OK
391	Canon	PIXMA iP3000	OK		OK
392	Canon	PIXMA iP3300	OK		OK
393	Canon	PIXMA iP3500	OK		OK
394	Canon	PIXMA iP4000	OK	OK	OK
395	Canon	PIXMA iP4200	OK		OK
396	Canon	PIXMA iP4300	OK		OK
397	Canon	PIXMA iP4500	OK		OK
398	Canon	PIXMA iP5000	OK		OK
399	Canon	PIXMA iP6000	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
400	Canon	PIXMA iP8500	OK		OK
401	Canon	PIXMA MP110	OK		OK
402	Canon	PIXMA MP130	OK		OK
403	Canon	PIXMA MP145	OK		OK
404	Canon	PIXMA MP150	OK		OK
405	Canon	PIXMA MP180	OK		OK
406	Canon	PIXMA MP450	OK		OK
407	Canon	PIXMA MP730	OK		OK
408	Canon	PIXMA MP780	OK		OK
409	Canon	PIXMA MP830	OK		OK
410	Canon	S-200SPX	OK		OK
411	Canon	S-520		OK	
412	Lexmark	C720		OK	
413	Lexmark	E230	OK		OK
414	Lexmark	E322	OK	OK	OK
415	Lexmark	Optra S1250		OK	
416	Lexmark	P4350	OK		OK
417	Lexmark	P6250	OK		OK
418	Lexmark	T420	OK	OK	OK
419	Lexmark	T620	OK	OK	OK
420	Lexmark	W812	OK	OK	OK
421	Lexmark	Z42	OK		OK
422	Lexmark	Z43	OK	OK	OK
423	Lexmark	Z45	OK		OK
424	Lexmark	Z55	OK	OK	OK
425	Lexmark	Z515	OK	OK	OK
426	Lexmark	Z615	OK		OK
427	Lexmark	Z705	OK	OK	OK
428	Star	NX-2420	—	OK	—
429	Brother	MFC 4800	OK	OK	OK
430	Brother	MFC 4800J	OK	OK	OK
431	Brother	MFC 6800	OK	OK	OK
432	Brother	MFC 7220	OK	OK	OK
433	Brother	MFC 7420	OK	OK	OK
434	Brother	MFC 7820N	OK	OK	OK
435	Brother	MFC 8840D	OK	OK	OK
436	Brother	MFC 210C	OK		OK
437	Brother	MFC 240C	OK		OK
438	Brother	HL1260		OK	
439	Brother	IntelliFax 2820	OK		OK
440	FUJI Xerox	Able 3321		OK	
441	FUJI Xerox	DL700		OK	
442	FUJI Xerox	DL900		OK	
443	FUJI Xerox	DL-3400		OK	
444	FUJI Xerox	DL-3800		OK	

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
445	FUJI Xerox	DL-3850		OK	
446	FUJI Xerox	DL-5800		OK	
447	FUJI Xerox	DL-6400Pro		OK	
448	FUJI Xerox	DL-6800		OK	
449	FUJI Xerox	DocuPrint 240A	OK	OK	OK
450	FUJI Xerox	FP 410		OK	
451	FUJI Xerox	Jet Wind 500C		OK	
452	FUJI Xerox	Phaser 3310	OK	OK	OK
453	FUJI Xerox	PP 10		OK	
454	Samsung	CLP-500	OK	OK	OK
455	Samsung	CLP-510	OK	OK	OK
456	Samsung	ML-1510/1710	OK	OK	OK
457	Samsung	ML-1520	OK		OK
458	Samsung	ML-1710	OK		OK
459	Samsung	ML-1750	OK	OK	OK
460	Samsung	ML-2010	OK		OK
461	Samsung	ML-2250	OK	OK	OK
462	Samsung	ML-2550	OK	OK	OK
463	Samsung	SCX-4016	OK	OK	OK
464	Samsung	SCX-4100/4106/4116/4216F	OK	OK	OK
465	Samsung	SRP 270		OK	
466	Sharp	AR-255		OK	
467	Sharp	AR-265FG		OK	
468	Sharp	AR-M160		OK	
469	Sharp	AR-M205		OK	
470	Sharp	AR-M207		OK	
471	Sharp	AR-M235		OK	
472	Sharp	AR-M275		OK	
473	Sharp	AR-M350		OK	
474	Sharp	AR-M400		OK	
475	Sharp	AR-M450		OK	
476	Kyocera	FS-1010	OK	OK	OK
477	Kyocera	FS-1010KX	OK		OK
478	Kyocera	FS-1020	OK	OK	OK
479	Kyocera	FS-1920	OK	OK	OK
480	Kyocera	FS-2000D	OK	OK	OK
481	Kyocera	FS-820	OK	OK	OK
482	Kyocera	FS-920	OK	OK	OK
483	Kyocera	FS-6020	OK	OK	OK
484	Kyocera	FS-6026	OK	OK	OK
485	Konica Minolta	Di152		OK	
486	Konica Minolta	Di 200/Di 250/Di 251		OK	
487	Konica Minolta	magicolor 2450	OK	OK	OK
488	Konica Minolta	magicolor 5450	OK	OK	OK
489	Konica Minolta	magicolor 7300	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
490	Konica Minolta	Magicolor 7300	OK		OK
491	Konica Minolta	PagePro 9100	OK		OK
492	Panasonic	KX-P1121		OK	
493	Panasonic	KX-P1123		OK	
494	Panasonic	KX-P1124		OK	
495	Panasonic	KX-P1624		OK	
496	Panasonic	KX-P6500		OK	
497	Panasonic	KX-P7100			
498	IBM	Infoprint 20		OK	
499	IBM	Infoprint 1116	OK	OK	OK
500	IBM	Infoprint 1312	OK	OK	OK
501	IBM	Infoprint 1316	OK	OK	OK
502	IBM	Infoprint 1332	OK	OK	OK
503	IBM	Infoprint 1412	OK	OK	OK
504	NEC	NEC P2200		OK	
505	NEC	NEC P3200		OK	
506	NEC	NEC P5300		OK	
507	NEC	NEC P8000		OK	
508	FUTEK	F8000		OK	
509	FUTEK	F84+		OK	
510	FUTEK	F86+		OK	
511	Avision	MF 3200	OK		OK
512	Avision	MF 3230	OK		OK
513	DATAMAX	I-4208		OK	
514	DATAMAX	I-4308		OK	
515	DOCUJet	1610F	OK	OK	OK
516	DOCUJet	UA1610	OK	OK	OK
517	OKI	Microline 391		OK	
518	OKI	B4350	OK	OK	OK
519	TOSHIBA	E-161	OK	OK	OK
520	TOSHIBA	Estudio-25		OK	
521	BENQ	CM3000	OK		OK
522	CityZen	GSX230		OK	
523	MITAC	MP-6600C		OK	
524	RICOH	NF3570		OK	